

# Nitrogen-Vacancy Photoionization from the Singlet State: Micro-diamond electrodes

Joe Becker

Texas A&M Department of Physics and Astronomy

*jbecker@physics.tamu.edu*

December 5, 2016



**PHYSICS & ASTRONOMY**  
TEXAS A&M UNIVERSITY

# Why Nitrogen-Vacancy Diamond Electrodes?

## Nitrogen-Vacancy as a Solid-State Electron Spin

The  $\text{NV}^-$  has the potential to be a solid-state realization of quantum system at room temperature. This has applications in


- Quantum Information and Metrology
- Nanoscale Magnetometry and Thermometry

## Photoionization as a New Approach to $\text{NV}^-$ Spin Control

- Ionization experiments can provide a new measurement of the singlet state
- Ionization can enhance current contrast of magnetic resonances
- Photocurrent can open an new avenue for spin-state measurements

# Nitrogen-Vacancy Diamonds


## NV Defect



I. V. Fedotov, et al. Sci. Rep. 4, 5362 (2014).


# Nitrogen-Vacancy Photoionization

## NV Energy and Fluorescence



# Enhanced Contrast ODMR Spectrum

## Optically Detected Magnetic Resonance




By increasing resonant peak contrast we:

- Improve signal to noise
- Increase sensitivity of magnetic field or temperature measurements



# Single-Photon Electroluminescence

## Ion-Microbeam Buried Electrodes




J. Forneris, et al. Nat. Publ. Gr. 1 (2015).

# Two Photon Photoionization



E. Bourgeois, et al. Nat. Commun. 6, 8577 (2015).


# Proposed Micro-diamond Electrode Process





## Current Progress


Currently we have successfully suspended a 100  $\mu\text{m}$  diamond within freely suspended SU8



We still need to find a polishing process that allows for a clean binding surface for silver coating.

# Photoionization Current Measurement

## Experimental Schematic



We intend to measure the photocurrent caused by photoionization in three wavelength regimes.

- 1 At 532 nm to verify a measured photocurrent (two-photon)
- 2 In the range of 470 to 500 nm (single-photon)
- 3 Then in the enhanced contrast ODMR regime with both green and blue light

# Conclusions

- Singlet state ionization is a single photon process.
- If we can ionize from the singlet state we should be able to measure a photocurrent with a linear dependence on pump power.
- Ionization from the singlet state will open the possibility of enhanced contrast ODMR. Increasing the sensitivity of  $\text{NV}^-$  based magnetometers and thermometers.